[MethodsX](https://doi.org/10.1016/j.mex.2020.100915) 7 (2020) 100915

Contents lists available at [ScienceDirect](http://www.ScienceDirect.com)

MethodsX

journal homepage: www.elsevier.com/locate/mex

Method Article

A simplified method to approximate a ROC curve with a Bézier curve to calculate likelihood ratios of quantitative test results

Walter Fierz

SVDI, Mittlere Haltenstr. 13, 3625 Heiligenschwendi, Switzerland

a b s t r a c t

In order to calculate likeli hood ratios (LR) values for quantitative test results, a distribution-independent algorithm based on Bézier curves is proposed. Receiver operating characteristic (ROC) analysis provides the LR as the slope of the tangent to the ROC curve at the point corresponding to the test result.

- Here, we make use of cubic Bézier curves defined by Bernstein polynomials of degree 3.
- A simplified method to adjust a Bézier curve to a ROC curve is presented

• The crucial advantage of this procedure is that Bézier curves are constructed by tangents to the ROC curve, whose slopes immediately provide the LR of a specific point on the curve.

> © 2020 The Author(s). Published by Elsevier B.V. This is an open access article under the CC BY license. [\(http://creativecommons.org/licenses/by/4.0/\)](http://creativecommons.org/licenses/by/4.0/)

a r t i c l e i n f o

Method name: A simplified method for adjusting Bézier curves to ROC data to calculate likelihood ratios of quantitative test results in medical diagnosis

Keywords: Receiver operating characteristics, Likelihood ratios, Bézier curves

Article history: Received 23 November 2019; Accepted 3 May 2020; Available online 16 May 2020

Specifications Table

E-mail address: wafierz@bluewin.ch

<https://doi.org/10.1016/j.mex.2020.100915>

2215-0161/© 2020 The Author(s). Published by Elsevier B.V. This is an open access article under the CC BY license. [\(http://creativecommons.org/licenses/by/4.0/\)](http://creativecommons.org/licenses/by/4.0/)

Simplified method

Background: Bayes' theorem

In medical laboratory diagnostics, the measured quantity in a test gives the physician a measure for estimating the significance of a test result for a particular diagnosis. However, it is left to the physician to assess a quantitative result as to its influence on judging the relevance for a particular disease. In principle, the physician starts with a suspicion for a particular disease. In order to confirm or refute the preliminary suspicion, the physician orders a specific laboratory test and a high result gives a stronger confirmation than a low result.

Formally, in Bayes' view: pretest odds multiplied by the likelihood ratio (LR) of the quantitative test result give the posttest odds.

Method

Receiver operating characteristic (ROC) analysis provides the LR as the slope of the tangent to the ROC curve at the point corresponding to the test result. A distribution-independent method has recently been described to calculate these slopes by adjusting Bézier curves to the ROC that are defined by tangents to a curve [\[1\]](#page-5-0) (Fierz, 2018). The mathematical basis of Bézier curves are Bernstein polynomials of degree n defined by

$$
B_{i,n}(t) = {n \choose i} t^i (1-t)^{n-i}
$$
 with t ranging from 0 to 1.

For the purpose here, we make use of cubic Bézier curves defined by

$$
B(t) = (1-t)^{3}P_{0} + 3t(1-t)^{2}P_{1} + 3t^{2}(1-t)P_{2} + t^{3}P_{3}
$$

[\(Fig.](#page-2-0) 1).

Here, a simplified method to adjust a Bézier curve to a ROC curve is presented. The procedure is based on a simplified method for the shape control of cubic Bézier curves [\[2\].](#page-5-0) In principle, the shape of the curve is defined by the two endpoints (P_0 and P_3) with the corresponding tangents to them and a shape control point $B(t)=S(u)$ on the curve [\(Fig.](#page-2-0) 2).

Procedure

Step1: Definition of the variable t of the Bézier curve

The variable t of the Bernstein polynomial has to be introduced and is defined here by $t_{xy} = (x + y)/2$ of the empirical ROC points.

Step 2: Selection of the endpoints of the Bézier curve [\(Fig.](#page-2-0) 2)

The endpoints of the Bézier curve $P_0=(x_0, y_0)$ and $P_3=(x_3, y_3)$ have to be chosen. Subsequently, the range of t has to be adjusted to the range from 0 to 1 as follows: $t_{xy} = ((x-x_0)/(x_3-x_0)+(y-y_0)/y_3-y_0)/2$

Step 3: Selection of the shape point of the Bézier curve [\(Fig.](#page-2-0) 2)

A shape point S(u) has to be chosen. It is recommended here that from the empirical ROC points the one which is closest to the upper left corner is used. This corresponds to the maximal Youden index (*J*=Se+Sp-1). The t value at that point is denoted u.

Step 4: Selection of tangent vectors at the endpoints of the Bézier curve [\(Fig.](#page-2-0) 2)

Apart from the endpoints P_0 and P_3 , and the shape point S the shape of the Bézier curve is defined by the two tangents at the endpoints:

 $T_0 = (g_0, h_0)$ and $T_3 = (g_3, h_3)$ are the tangents vectors at P_0 and P_3 respectively. To start with it is recommended to set

Fig. 1. Principle of constructing cubic Bézier curves. First, the lines between the control points P0, P1, P2, and P3 are divided by the ratio t leading to T1, T2, and T3. Second, the lines between T1, T2, and T3 are again divided by the ratio t leading to T4, and T5. Third, the line between T4, and T5 is again divided by the ratio t leading to B(t) on the Bézier curve. The line between T4, and T5 is the tangent to $B(t)$.

Pierre Bézier (1910–1999) was a French engineer who developed a method of producing computer-driven curves to be used in the design of automobiles at Renault, which came to be known as Bézier curves.

Fig. 2. Shape definition of the Bézier curve. Apart from the endpoints P_0 and P_3 , and the shape point S the shape of the Bézier curve is defined by the two tangents at the endpoints.

Fig. 3. Calculation of P_1 and P_2 . P_1 and P_2 of the Bézier curve can be calculated according to (Yang & Huang, 1993).

 $T_0 = (0, 1)$ (vertical line) and

 $T_3 = (1, 0)$ (horizontal line) as in an ideal ROC curve.

Later, g_0 and h_3 can be adjusted to reach an optimal fit of the Bézier curve to the empirical ROC points.

Step 5: Calculation of P1 and P2 of the Bézier curve (Fig. 3)

 P_1 and P_2 of the Bézier curve can be calculated according to (Yang & Huang, 1993) with two shape parameters α and β and the following relations:

$$
P_1 = (\alpha/3)T_0 + P_0
$$
, and $P_2 = (\beta/3)T_3 + P_3$

$$
\alpha = \frac{\begin{vmatrix} (x_u - a * x_0 - b * x_3) & g_3 \\ (y_u - a * y_0 - b * y_3) & h_3 \end{vmatrix}}{u * (1 - u)^2 * \Delta} \text{ and } \beta = \frac{\begin{vmatrix} (x_u - a * x_0 - b * x_3) & g_0 \\ (y_u - a * y_0 - b * y_3) & h_0 \end{vmatrix}}{u^2 * (1 - u) * \Delta}
$$

where the notation | | denotes the determinant operator

with
$$
a = (1 - u)^2 * (1 + 2u)
$$
, $b = u^2 * (3 - 2u)$ and $\Delta = \begin{vmatrix} g_0 & g_3 \\ h_0 & h_3 \end{vmatrix}$

Step 6: Calculation of the tangent slopes [\(Fig.](#page-4-0) 4)

With P0,1,2,3 being established in this way, the slopes of the tangents, i.e. the LR(t), can be calculated for all t with

$$
LR(t) = \frac{P1y * (1 - 2t) - (P1y - P2y) * (2t - 3t^{2}) + P3y * t^{2} - P0y * (1 - t)^{2}}{P1x * (1 - 2t) - (P1x - P2x) * (2t - 3t^{2}) + P3x * t^{2} - P0x * (1 - t)^{2}}
$$

Validation

To demonstrate the procedure, data from a prosteate-specific antigen (PSA) study are used [\[3\]](#page-6-0) (Thompson et al., 2005) with the ROC analysis: Gleason Grade >7 ($n = 250$) vs Gleason Grade $<$ 7 or No Cancer (*n* = 5325):

Fig. 4. With P_{0,123} being established in this way, the slopes of the tangents, i.e. the LR(t), can be calculated for all t.

Fig. 5. Relation between the quantitative test results and the LR(t)s. Three different calculations according to step 7.

"Conclusion (by the authors): There is no cutpoint of PSA with simultaneous high sensitivity and high specificity for monitoring healthy men for prostate cancer, but rather a continuum of prostate cancer risk at all values of PSA."

Step 7: Application to PSA test results (Figs. 5 and [6\)](#page-5-0)

Fig. 6. Relation between PSA test results an LRs. LR =1 corresponds to 2.2 ng/ml PSA. Values below 2.2 ng/ml have a LRs <1, values above have LRs >1 .

The relation between the quantitative test results and their position on the Bézier curve and thereby the LR(t)s has to be established, which of course depends on the test parameter, in this case PSA. This can be done in three ways:

- 1. Most directly, the LRs of the individual empirical points on the ROC curve are calculated in step 6 and fitted to a curve.
- 2. More indirectly, a l value based on LR, i.e. $l = 1/(1+LR)$ is fitted to the quantitative test values.
- 3. The t values of the ROC data points are fitted to the test values.

In either way, preferring the method that gives the best fit, the diagnostic LR can be calculated from all quantitative test results.

Acknowledgements

This is where you can acknowledge colleagues who have helped you that are not listed as coauthors, and funding. MethodsX is a community effort, by researchers for researchers. We highly appreciate the work not only of authors submitting, but also of the reviewers who provide valuable input to each submission. We therefore publish a standard "thank you" note in each of the articles to acknowledge the efforts made by the respective reviewers.

Declaration Competing of Interest

The authors declare that they have no known competing financial interests or personal relationships that could have appeared to influence the work reported in this paper.

References

^[1] W. Fierz, Likelihood ratios of quantitative laboratory results in medical diagnosis: the application of Bézier curves in ROC analysis, PLoS ONE 13 (2018) 1–9 [https://doi.org/10.1371/journal.pone.0192420.](https://doi.org/10.1371/journal.pone.0192420)

- [2] S. Yang, M. Huang, A new shape control and classification for cubic Bezier curves, in: N.M. Thalmann (Ed.), Commun. with Virtual Worlds, Springer-Verlag, Tokyo, 1993, pp. 204–215 https://doi.org/10.1007/978-4-431-68456
- I3] I.M. Thompson, D.P. Ankerst, C. Chi, M.S. Lucia, P.J. Goodman, J.J. Crowley, H.L. Parnes, C.A. Coltman, Operating Characteristics of prostate-specific antigen in men with an initial PSA Level of 3.0ng/mL or Lower, J. A [https://doi.org/10.1001/jama.294.1.66.](https://doi.org/10.1001/jama.294.1.66)