

Protocol

Obtaining patient-derived cancer organoid cultures via fine-needle aspiration



Patient-derived tumor organoid cultures are an essential and innovative methodology for translational research. However, current techniques to establish these cultures are cumbersome, expensive, and often require irreplaceable clinical tissue from surgery or core biopsies. Fine-needle aspiration (FNA) provides a minimally invasive biopsy technique commonly performed in clinical settings. Here, we provide a protocol for FNA. We have found that FNA provides a cost-effective, rapid, and streamlined method for tissue acquisition for cancer organoid culture.

Courtney J. Phifer, Kensey N. Bergdorf, Matthew E. Bechard, ..., Oliver G. McDonald, Ethan Lee, Vivian L. Weiss

vivian.l.weiss@vumc.org

HIGHLIGHTS

Fine-needle aspiration (FNA) to obtain patientderived organoid cultures

FNA offers a costeffective and minimally invasive method to obtain tissue

FNA-based organoid cultures can be used for many downstream applications

Phifer et al., STAR Protocols 2, 100220 March 19, 2021 © 2020 The Author(s). https://doi.org/10.1016/ j.xpro.2020.100220



Protocol Obtaining patient-derived cancer organoid cultures via fine-needle aspiration

Courtney J. Phifer,¹ Kensey N. Bergdorf,² Matthew E. Bechard,¹ Anna Vilgelm,³ Naira Baregamian,^{4,5} Oliver G. McDonald,^{1,5,6} Ethan Lee,^{2,5,7} and Vivian L. Weiss^{1,2,5,8,9,*}

¹Department of Pathology, Microbiology, and Immunology, Vanderbilt University Medical Center, Nashville, TN 37232, USA

²Department of Pharmacology, Vanderbilt University, Nashville, TN 37232, USA

³Department of Pathology, Ohio State University, Columbus, OH 43210, USA

⁴Department of Surgery, Vanderbilt University Medical Center, Nashville, TN 37232, USA

⁵Vanderbilt Ingram Cancer Center, Vanderbilt University Medical Center, Nashville, TN 37232, USA

⁶Epithelial Biology Center, Vanderbilt University Medical Center, Nashville, TN 37232, USA

⁷Department of Cell and Developmental Biology, Nashville, TN 37232, USA

⁸Technical Contact

⁹Lead Contact

*Correspondence: vivian.l.weiss@vumc.org https://doi.org/10.1016/j.xpro.2020.100220

SUMMARY

Patient-derived tumor organoid cultures are an essential and innovative methodology for translational research. However, current techniques to establish these cultures are cumbersome, expensive, and often require irreplaceable clinical tissue from surgery or core biopsies. Fine-needle aspiration (FNA) provides a minimally invasive biopsy technique commonly performed in clinical settings. Here, we provide a protocol for FNA. We have found that FNA provides a cost-effective, rapid, and streamlined method for tissue acquisition for cancer organoid culture.

For complete details on the use and execution of this protocol, please refer to Lee et al. (2020) and Vilgelm et al. (2020).

BEFORE YOU BEGIN Matrigel preparation

© Timing: 6–8 h

- 1. Aliquot Matrigel
 - a. Remove stock bottle of Matrigel from -20° C storage and thaw at 4°C for 6–8 h.
 - b. Place stock bottle of Matrigel on ice in a sterile environment, as it will be used for tissue culture.
 - c. Aliquot 1 mL of Matrigel into labeled microcentrifuge tubes and immediately place aliquots on ice.
 - d. Store aliquots at -20° C for long-term storage.

Note: Aliquots can be thawed at 4°C and we have kept aliquots at 4°C for up to a week to prevent additional freeze-thaw or waste.

Media preparation

© Timing: 2 h





2. Media Component Aliquot Preparation

- a. Aliquot fetal bovine serum (FBS)
 - i. Thaw 500 mL bottle of FBS at 4°C.
 - ii. Aliquot 45 mL of FBS into labeled 50 mL conical tubes.

Note: If more than 45 mL of FBS is aliquoted into a 50 mL conical, upon refreezing, the FBS can leak.

- b. Aliquot L-glutamine
 - i. Thaw bottle of L-glutamine at 4°C for 12–24 h for next-day aliquoting or quickly in 37°C water bath. Aliquot 6 mL of L-glutamine into labeled 15 mL conical tubes.
- c. Aliquot penicillin-streptomycin (pen/strep)
 - i. Thaw bottle of pen/strep at 4°C for 12–24 h for next-day aliquoting or quickly in a 37°C water bath.
 - ii. Label appropriate amount of 15 mL conical tubes.
 - iii. Aliquot 6 mL of pen/strep into labeled 15 mL conical tubes.
- d. Store all aliquots at $-20^{\circ}C$.

Note: Once prepared, aliquots can be thawed for 12–24 h at 4° C for next-day use, or in a 37° C water bath for immediate use.

3. Prepare Complete DMEM and Complete Media as described in the Materials and Equipment section.

Pre-warm plate and complete media

© Timing: 20 min

- 4. Place a 6-well plate in the incubator to warm for at least 20 min before use.
- 5. Aliquot 20 mL of Complete Media and place in a 37°C water bath for at least 20 min before use.

KEY RESOURCES TABLE

REAGENT or RESOURCE	SOURCE	IDENTIFIER
Chemicals, peptides, and recombinant proteins		
Dulbecco's modified Eagle's medium (DMEM)	Sigma	D6429-500ML
BioWhittaker RPMI-1640 cell culture media, Lonza (RPMI)	VWR	12001-534
Nutrient mixture F-12 Ham (Ham's F12)	Sigma	N4888-500ML
MCDB 105 medium, unmodified	Cell Applications	117-500
Penicillin-streptomycin	Sigma	P4333-100ML
L(+)-Glutamine 200 mM 100×	VWR	VWRL0131-0100
Normocin	Invivogen	ant-nr-1
Fetal bovine serum (FBS)	Thermo Fisher Scientific	26140079
B-27 supplement	Gibco	17504044
Matrigel	Fisher Scientific	CB-40234
Trypsin (EDTA 0.25%)	Gibco	25200056
Dimethyl sulfoxide (DMSO)	Sigma	D8418
	(C	ontinued on next page)

Protocol



Continued

REAGENT or RESOURCE	SOURCE	IDENTIFIER
Phosphate-buffered saline (PBS)	Corning	MT21040CV
Other		
24-well Corning Costar ultra-low-attachment microplates, sterile	Fisher Scientific	07-200-602
6-well CELLSTAR cell culture multiwell plates, polystyrene, Greiner Bio-One, sterile	VWR	82050-842
VWR T75 cell culture flasks, sterile	VWR	10062-860
Low-retention filter tips, 1,000 μ L, sterile	VWR	89174-530
Low-retention filter tips, 200 $\mu\text{L},$ sterile	VWR	89174-526
Low-retention filter tips, 20 μ L, sterile	VWR	89174-524
Syringe holder, 10 mL	Belpro Medical	938
BD PrecisionGlide single-use needles: regular bevel, regular wall, 25-gauge	Fisher Scientific	14-821-13D
10 mL Fisherbrand sterile syringes for single use	Fisher Scientific	14-955-459
VWR centrifuge tube, flatcap, sterile, 50 mL	VWR	76176-952
VWR disposable aspirating pipets, individually wrapped, sterile	VWR	414004-265
VWR disposable plugged 5 mL serological pipets, individually wrapped, sterile	VWR	89130-896
VWR disposable plugged 10 mL serological pipets, individually wrapped, sterile	VWR	89130-898
VWR disposable plugged 25 mL serological pipets, individually wrapped, sterile	VWR	89130-900
Wobble-not plugged 50 mL serological pipets, individually wrapped, sterile	VWR	75993-434
CryoCooler freeze controller (Mr. Frosty)	VWR	414004-284
Corning cell scrapers	Fisher Scientific	07-200-365
50 mL conical tubes	N/A	N/A
15 mL conical tubes	N/A	N/A
Petri dishes	N/A	N/A
Forceps, sterile	Sklar	96-2917
Cryovials	VWR	10018-754
Hemocytometer	N/A	N/A
Specimen cup	N/A	N/A
CO ₂ incubator	N/A	N/A
Water bath	N/A	N/A
P1000	N/A	N/A
P200	N/A	N/A
P20	N/A	N/A
Easypet	N/A	N/A
Centrifuge	N/A	N/A
Biosafety cabinet	N/A	N/A
−80°C freezer	N/A	N/A
Liquid nitrogen freezer	N/A	N/A





MATERIALS AND EQUIPMENT

Complete DMEM

Reagent	Final concentration (mM or μ M)	Amount
DMEM	44%	250 mL
Ham's F12	22%	125 mL
MCDB	22%	125 mL
FBS	10%	56 mL
L-Glutamine	0.9%	5.6 mL
Penicillin-streptomycin	0.9%	5.6 mL
Normocin	0.2%	1.2 mL
Total	100%	568.4 mL

▲ CRITICAL: Certain cell types (i.e., gastrointestinal and pancreaticobiliary) may require the use of Advanced DMEM with supplements that assist with growth (i.e., Glutamax, Epidermal Growth Factor (EGF), Fibroblast Growth Factor (FGF), Insulin-Transferrin-Selenium (ITS)).

Note: Normocin is added to prevent mycoplasma contamination.

Note: Instead of penicillin-streptomycin, Antibiotic-Antimycotic (100×) (Thermo Fisher, 15240062) can be substituted to help prevent fungal growth that is common in animal FNAs.

Note: Complete DMEM should be stored at 4° C and can be used for up to one month after preparation.

Complete media

Reagent	Final concentration (mM or μ M)	Amount
Complete DMEM	98%	515 mL
B27	2%	10.5 mL
Total	100%	525.5 mL

Note: Store complete media at 4°C when not in use. The media expires approximately 1 month after it is freshly made.

▲ CRITICAL: All media should be prepared in a biosafety cabinet to ensure sterility. If sterility problems occur, the media can be filtered following preparation.

STEP-BY-STEP METHOD DETAILS

Ex vivo specimen fine-needle aspiration (FNA)

© Timing: 15-30 min

Fine-needle aspiration is a technique commonly used in a clinical setting to obtain cells for cytopathology and genetic testing. Here, we apply it to a research setting to obtain cells and cell clumps that will generate organoid cultures. FNA is advantageous over traditional digestion methods because it is much more gentle, allowing for increased cell survival.

Protocol



- ▲ CRITICAL: The specimen and FNA-setup must be sterile for tissue culture. If performing the FNA on a specimen, obtain the tissue in a sterile fashion from surgery. If obtaining tissue from surgical pathology, ensure that sterile ink is used to mark the margins prior to FNA, as the ink in surgical pathology grossing rooms is often not sterile. If obtaining the specimen from an animal, ensure sterile technique when performing *in vivo* FNAs or when performing surgery on animals.
- 1. Attach a sterile 25-gauge beveled needle to a sterile 10 mL luer-lock syringe and insert into a syringe holder.
- 2. If using surgical tissue, transfer specimen to a sterile petri dish within a laminar flow biosafety cabinet. If performing FNA *in vivo*, perform in a procedure room with sterile technique.
- 3. Immobilize the specimen/nodule with sterile-gloved fingers or sterile forceps and using your other hand, insert the needle with the syringe holder perpendicular to the specimen/ nodule.
- 4. Apply backward pressure to the syringe using the syringe holder, while rapidly agitating back and forth in a "saw-like" motion within the specimen at a rate of 2–3 strokes per second (Methods Video S1). This motion loosens tumor and other cells from the stromal matrix. One "needle pass" typically involves 10–20 forward strokes (excursions). For optimal tumor sampling, reangle the needle slightly with each excursion so that sampling occurs in a fan shape. The needle should not come out of the specimen/nodule until the 10–20 excursions have been completed and material is visible in the needle hub. The needle should not protrude from the opposite side of the specimen at any point. Troubleshooting 1

Note: Traditionally, FNA is performed on patients when the nodule is 1 cm or greater in greatest dimension. However, *ex vivo* FNA has been successfully performed on specimens as small as 2 mm with adequate yield for organoid culture, including heavily fibrotic tumors.

- ▲ CRITICAL: The speed of the agitation/strokes/excursions is critical for cellular yield. If your yield is low, check that your stroke rate is at least 2–3 strokes per second and that needle is not passing through the tissue.
- 5. Once material is visible in the hub of the needle, release suction and remove the needle from the specimen.
 - \vartriangle CRITICAL: Suction should always be released prior to removing the needle from the specimen.
- Following this process (a "needle pass"), rinse the needle in 20 mL of sterile, pre-warmed, RPMI or DMEM in a 50 mL conical tube. Expel needle contents into the conical tube and rinse needle 2–3 times.

Note: Extensive rinsing (more than 3–4 times) will lead to increased cell shearing and lower yields.

- 7. Repeat steps c-f 3-5 times.
- 8. Dispose of syringe and needle in appropriate sharps container.
 - ▲ CRITICAL: FNA yield is directly correlated with the experience of the person performing the technique. We recommend extensive practice on fruit or store-bought meat prior to attempting FNA on animals or critical specimens. In addition, different tumors may have different yields. Tumors with extensive necrosis or fibrosis may give lower viable cell yields.







Figure 1. Summary of steps for plating cells from FNA

Collect cells via FNA. After the FNA, half the cells are plated in semi-solid culture in a 24-well ultra-low attachment plate. The other half of the cells are plated in a 6-well plate in the 75% Matrigel disc culture.

Cell growth protocol

© Timing: 1–4 weeks

Once you have obtained the cells from the FNA, they can be immediately plated using one of two culture methods. Semi-solid culture is useful for longer culture periods and free movement of cells. Disc culture can be beneficial for more compact organoid growth and allows for generation and propagation of two-dimensional cultures. We recommend using both semi-solid and disc culture methods for new organoid cultures, as the growth needs vary from sample to sample. See Figure 1. For a summary of steps used in FNA-based organoid culture.

- 9. Centrifuge the FNA material in the conical tube at 340 \times g for 5 min at 20°C–25°C.
- 10. Aspirate the supernatant and resuspend the pellet in Complete Media.

Note: If using only one plating method, we recommend resuspending the FNA material in 300 μ L. If both plating methods are to be used, we recommend resuspending the FNA material in 600 μ L and dividing into two 300 μ L aliquots.

- 11. Cells can be plated in semi-solid culture to obtain organoids, or in disc culture to obtain both organoids and 2D cell cultures.
 - a. Semi-solid culture
 - i. Pipet and mix 300 μL of the FNA cell suspension with 5% Matrigel in complete media with an additional 2% FBS.
 - ii. Pipet 550 μ L cell suspension in a 24-well low-attachment plate following a figure 8 motion while gently expelling cell suspension.
 - iii. Place the cells in the incubator.
 - iv. Replenish 200 μL per well of fresh complete media, 5% Matrigel, and 2% FBS dropwise weekly.
 - v. Passage cells as needed. Troubleshooting 2.
 - ▲ CRITICAL: In this type of culture, the low percentage of Matrigel makes the matrix fragile and is more susceptible to media evaporation. Troubleshooting 3.
 - b. Disc culture (Figure 2)
 - i. Pipet and mix 300 μL of the FNA cell suspension with 75% Matrigel and 25% complete media.







Figure 2. Two-dimensional cultures can be derived from disc culture

(A) Animated figure of disc culture organoids with 2Ds undermining the disc.
(B) Bright-field image of a patient-derived melanoma organoid 6 days after plating in disc culture with 2Ds undermining the disc culture at 10×. Scale bar, 100 μm.

- ii. Add three 50 μ L drops (disc) to each well of a pre-warmed 6-well plate. Alternatively, you can plate a single 150–200 μ L disc per well of the 6-well plate.
- iii. Place the plate in a tissue culture incubator for 10 min to allow the Matrigel to solidify.
- iv. Cover cells with warmed complete media by slowly pipetting the media down the side of the well until the discs are completely covered (~2.5 mL).
- v. Place cells back in the incubator.
- vi. Replace media every 2–3 days by aspirating off the old media and replacing it with prewarmed complete media following the step 11b.v. Troubleshooting 4
- c. 2-dimensional (2D) cell culture (Figure 2)
 - i. Follow the disc culture protocol until 2D cells have undermined the disc.
 - ii. Freeze the disc down following the freezing cells protocol.
 - iii. Add 2 mL of 20°C–25°C complete media to each well after removing disc. Make sure media is either 4°C or 20°C–25°C, as 37°C media could shock the cells.
 - iv. While in a 6-well plate, replace media with fresh, pre-warmed media every 2-3 days.
 - v. Once cells are confluent, passage them from the 6-well plate to a T75 flask following step 2a in the passaging cells protocol.
 - vi. In the T75, replace three-fourths (~11 mL) of complete media with fresh complete media weekly.
 - vii. Passage cells as needed.

Note: If 2D culture is not desired, plate in a low-attachment plate in the semi-solid format. Low-attachment plates prevent the matrix disrupting 2D cells from growing underneath the organoids.

Passaging cells

© Timing: 15 min

Cells should be passaged when media needs replaced or replenished more often than twice a week or when organoids are harvested for experimental use.

12. Semi-solid culture (Figure 3)

- a. Pipet the organoid suspension with a P1000.
- b. In order to break up the Matrigel/organoids, draw a small amount of organoid suspension up into the pipet and then expel it slowly while moving the pipet in a circular motion in the plate. Repeat this 2-4 times.
- c. Transfer the cell suspension to a 50 mL conical tube.
- d. Centrifuge the cell suspension at 340 \times g for 5 min at 20°C–25°C and aspirate off the supernatant.
- e. Resuspend the pelleted cells in complete media.







Figure 3. Passaging of semi-solid cultures

(A) Once the organoids are centrifuged, resuspend and aliquot (B) the desired amount for replating then use the rest for freeze downs. (C) For a 1:4 passage resuspend in 2,800 μ L and pipet 700 μ L in a new conical (to replate). The remaining 2,100 μ L is sufficient for 3 freeze downs.

- f. Pipet out the desired amount of the cell suspension and replate following step 12b in the cell growth protocol.
- g. Either discard the remaining cell suspension or save for other uses (e.g., freezing, plating for experiments, etc.)
- 13. Disc culture
 - a. Remove media and add 1 mL ice-cold PBS to each well.
 - b. Scrape discs gently off of the plate with a cell scraper.
 - c. Pipet ice-cold PBS to break apart discs and collect into a 1.5 mL microfuge tube.
 - d. Centrifuge cells at 340 × g for 5 min at 20°C–25°C then remove PBS and Matrigel overlying the pellet.
 - e. Wash pellet gently with 1 mL 4°C PBS and centrifuge 340 \times g for 5 min at 20°C–25°C.
 - f. Remove PBS and resuspend cell pellet in 3× Matrigel (for a 1:3 split) then plate in prewarmed 6-well plate.
- 14. 2D cell culture
 - a. Passaging from a 6-well to a T75 flask
 - i. Aspirate off all the media.
 - ii. Add 1 mL of trypsin to each well.
 - iii. Incubate at 37°C for 3 min.
 - iv. Pipet trypsinized cells from each well into a conical tube with 20 mL of DMEM or RPMI.
 - v. Centrifuge the cell suspension at 340 \times g for 5 min at 20°C–25°C and aspirate off the supernatant.
 - vi. Resuspend cell pellets in 1 mL of complete media then transferred to a T75 containing 14 mL of complete media.
 - vii. Rock the T75 back and forth until the bottom is covered with cell suspension.
 - viii. Place in the incubator.

Note: Depending on the number of cells, multiple T75s might be needed.

Freezing cells

© Timing: 15 min

As these cultures come from *ex vivo* tissue, they are not easily replaceable or replicable. We recommend freezing down multiple vials of any organoid cultures before beginning experiments, as these

STAR Protocols Protocol



cultures can be fragile and do change over time. Freeze downs enable preservation of the cultures should there be a contamination or error in propagation.

- 15. Obtaining Cells
 - a. Disc Culture
 - i. Aspirate off media.
 - ii. Pipet 1 mL of 4 $\!\!\!\!C$ PBS directly on to the disc in each well.
 - iii. Use a cell scraper to gently scrape off any remaining disc.
 - iv. Pipet cell suspension into a 1.5 mL microfuge tube.
 - v. Pipet up and down several times to dissolve the Matrigel.
 - b. Semi-solid Culture
 - i. Follow the relevant steps in the Passaging Cells protocol and save the remaining cell suspension.
 - c. 2D culture
 - i. Follow relevant steps in the Passaging Cells protocol and save the remaining cell suspension.
 - ii. Pipet 20 μL into a hemocytometer to count the number of cells.
- 16. Centrifuge the cell suspension at 340 \times g for 5 min.
- 17. Aspirate off the supernatant and resuspend in complete DMEM.
 - a. For disc and semi-solid culture, deposit approximately 2 wells per cryovial.
 - b. For 2D culture, deposit 300,000–1,000,000 cells per cryovial.

Note: For disc culture and semi-solid culture, the number of wells per cryovial can vary depending on amount and size of organoids.

- 18. Pipet 700 μ L of cell suspension into each appropriately labeled cryovial.
- 19. Pipet 200 μ L of FBS into each cryovial.
 - ▲ CRITICAL: Complete steps 18 and 19 with all cryovials before moving to step 20 because once DMSO is added, it starts killing cells.
- 20. Pipet 100 μL of DMSO into a cryovial.
- 21. Screw the cap on tightly and invert 2–3 times.
- 22. Place directly into a Mr. Frosty.
- 23. Repeat steps 20–22 until all the cryovials are complete.
- 24. Tighten the lid on the Mr. Frosty and place directly into a -80° C freezer.
- 25. Keep cells in Mr. Frosty for at least 24 h and then they can be transferred to a box prior to transfer to liquid nitrogen for long-term storage.
- 26. After a week in the -80°C freezer, transfer cells to a liquid nitrogen freezer at or below -130°C for longer storage.

▲ CRITICAL: It is important to complete steps 20–24 as quickly as possible to prevent cell loss.

II Pause Point: Cells can be stored in the -80° C freezer for up to a week and longer term at or below -130° C in a liquid nitrogen freezer.

Thawing cells

© Timing: 15 min

Cultures must be properly thawed to give the cells the best chance of recovery. Growth may not immediately match that of the culture prior to being frozen but should pick up within a week or two after thawing.



STAR Protocols Protocol





Figure 4. Images of patient-derived cancer organoids

(A) Bright-field images of patient-derived melanoma organoids plated in disc culture 6 days after plating $10 \times$. Scale bars, 100 μ m.

(B) Bright-field images of patient-derived thyroid organoids plated in semi-solid culture 21 days after plating 10 \times . Scale bars, 100 μm .

27. Preheat water bath to 37°C.

- 28. Pipet 20 mL of media into a 50 mL conical tube warm to \sim 24° C.
- 29. Obtain cryovial with cells.

Optional: If thawing more than one or two cryovials at a time, store the other cryovials on dry ice until ready to thaw.

- 30. Place cryovial in water bath.
- 31. Incubate for 1 minute then check to see if it has thawed. If not, check in 15–30 s intervals until thawed.
- 32. Once thawed, pipet contents from cryovial into the media from step 28.
- 33. Rinse the cryovial with 1,000 μL of the media from step 32 and pipet it back into the conical tube.
- 34. Screw the conical tube lid tightly and invert to ensure adequate mixing.

Note: This is to ensure the DMSO is diluted adequately.

- 35. Centrifuge at 340 \times g for 5 min.
- 36. Aspirate off the supernatant.

Optional: Resuspend in 20 mL of media or PBS, centrifuge at 340 \times g for 5 min, and aspirate off the supernatant.

37. Resuspend and plate as desired following steps in the Cell Growth Protocol.

EXPECTED OUTCOMES

This protocol describes an effective and minimally invasive method to establish patient-derived cell lines and three-dimensional growth of these cells. Between one to three weeks of culture, single cells and small clusters obtained from FNA grow to create small organoids (Figure 4). Initial organoid culture success rates and long-term propagation rates following cryopreservation can be found in Vilgelm et al., 2020.

STAR Protocols Protocol



LIMITATIONS

Not all tumors robustly produce organoids, although most tumors we assessed grow with this method including thyroid, colon, pancreas, gastric, renal, and melanoma. We recommend utilizing both culture methods when a sample is collected (semi-solid and disc), as some samples will preferentially grow in the semi-solid culture, while others will preferentially grow as discs. In addition, not all tumor types will generate a robust population of 2D cells. Two-dimensional cultures are typically composed of both fibroblasts and tumor cells, with the fibroblast percentage increasing with each passage. In our hands, thyroid and melanoma grow the most robust 2D cultures, with gastrointestinal and renal tumors having fewer or no 2D cells.

It is vital to obtain the sample directly from surgery or as soon as it reaches surgical pathology. This is to make sure the samples are sterile. If the sample is not obtained during these times, the grossing/ dissection in surgical pathology can cause contamination or cell death (i.e., ink, formalin, etc.).

TROUBLESHOOTING

Problem 1 Clogged needle during FNA.

Potential solution

• Very carefully unscrew the needle while holding the syringe holder/syringe combination. Pull the stopper back on the syringe holder/syringe combination then screw the needle back on. Put the needle in the rinsing media and press down forcefully on the stopper.

Problem 2

Organoid clumping after plating and during growth.

Potential solution

- To ensure even distribution of cells, pipet the cell suspension very well or invert to mix approximately 10 times.
- Mixing the cells well before adding the Matrigel. While working with Matrigel, make sure to keep it and anything that contains it on ice until it is ready to start solidifying.
- Pipetting vigorously can create heat and cause the Matrigel to start solidifying so mix keep the cell suspension with Matrigel on ice.
- When plating semi-solid culture, pipet the cell suspension in a figure 8 motion while plating.

Problem 3

Media evaporation.

Potential solution

- To grow robust cultures, some lines may need to be incubated for many weeks. Because of this, they can be prone to evaporation of complete media. To decrease evaporation, plate the cultures in the middle of the plate and fill the surrounding empty wells in the plates with sterile PBS.
- Replenish the water pans in the incubator frequently to maintain humidity.
- Place cells in a separate incubator that is not accessed as frequently to decrease exposure to door opening.
- Replace or replenish the media more frequently.

Problem 4

Disc detachment from plate.





Potential solution

- Always use warmed media (37°C) when changing the media on disc cultures to prevent disruption of the Matrigel matrix. Cold media causes the Matrigel to dissociate.
- Pipet carefully down the side of each well to prevent disc detachment.
- Pre-warm the plate prior to plating the disc culture ensures better attachment.
- When 2D cells extensively undermine the discs, the disc can detach, so this is a good point to freeze down the organoid disc.

RESOURCE AVAILABILITY

Lead contact

Further information and requests for resources and reagents should be directed to and will be fulfilled by the Lead Contact, Vivian Weiss, (vivian.l.weiss@vumc.org).

Materials availability

This study did not generate new unique reagents.

Data and code availability

This study did not generate or analyze any datasets or code.

SUPPLEMENTAL INFORMATION

Supplemental Information can be found online at https://doi.org/10.1016/j.xpro.2020.100220.

ACKNOWLEDGMENTS

The project described was supported by the National Center for Research Resources, grant UL1 RR024975-01, and is now at the National Center for Advancing Translational Sciences, grant 2 UL1 TR000445-06. The content is solely the responsibility of the authors and does not necessarily represent the official views of the NIH. The project described was also supported by American Thyroid Association (2019-0000000090 to V.L.W.), K12 Vanderbilt Clinical Oncology Research Career Development Program (NCI K12CA090625 to V.L.W.), V Foundation Scholar Award (to V.L.W.), Children's Cancer Research Fund Emerging Scientist Grant (to V.L.W.), ACS (133934-CSDG-19-216-01-TBG to V.L.W.), NIH R37 (CA233770 to A.V.), Training in Pharmacological Sciences NIH T32GM007628-42 (to K.N.B.), NIH K08 (1K08 CA240901-01A1 to V.L.W.), NIH R35GM122516, and R01CA224188 (to E.L.). Figures 1, 2A, and 3 and Video S1 were created with Biorender.com.

AUTHOR CONTRIBUTIONS

C.J.P. wrote the paper; K.N.B. edited the paper and assisted with figures; M.E.B. and E.L. edited the paper; A.V., N.B., O.G.M., and V.L.W. isolated patient tissue, consented patients, designed the methodology, and edited the paper.

DECLARATION OF INTERESTS

The authors declare no competing interests.

REFERENCES

Lee, M., Bergdorf, K., Phifer, C., Jones, C., Byon, S., Sawyer, L., Bauer, J., and Weiss, V. (2020). Novel three-dimensional cultures provide insights into thyroid cancer behavior. Endocr. Relat. Cancer 27, 111–121. Vilgelm, A., Bergdorf, K., Wolf, M., Bharti, V., Shattuck-Brandt, R., Blevins, A., Jones, C., Phifer, C., Lee, M., Lowe, C., et al. (2020). Fine-needle aspiration-based patient-derived cancer organoids. iScience 23, 101408.